

## Cotton Candy Machine Instructions

- Set machine base on a steady surface.
- Release the two bolts on the top – unscrew completely.
- Plug in the machine and place the bowl and dome on top.
- Pour sugar floss into the center opening of the base.
- Make sure the dial is turned to low heat – flip on the heat and motor switches.
- Turn up heat slowly and wait for the floss to come out.
- Once floss starts to build up on the sides of the bowl use a cone to gather up the floss in a counterclockwise direction.
- For continuous floss production you can leave the motor running and add sugar. Turn motor switch off if you need to stop.
- When you are finished – turn off the machine and unplug – remove the dome and bowl and tighten up the two bolts on the top of the base for transport.
- No need to clean – we take care of that for you.

**ENJOY!**